


Installation instructions for linear LED modules

The following instructions demonstrate how easy it is to install linear LED modules.*

Product overview

The following products are required for the installation of linear LED modules:

- LINEARlight module
- Matching OPTOTRONIC control gear
- Feeder: CONNECTsystem
- End caps (one for the input side and one for the output side)
- Mounting clips



Instructions



1. Connect the feeder with the module. Attention: The cable on the connector at the end of the feeder has to point upward.



2. Attach the optional end cap (accessory) with OSRAM stamp to get the strain relief function on the input side.




3. Attach the optional end cap (accessory) without OSRAM stamp in order to finish the module and to get the strain relief function for the connecting cables.




4. Open the cap of the control gear.

*Please observe the safety and mounting information specified in the product data sheets.



4. Connect the power supply cables (observe correct polarity) and close the cap.



5. Completed system with mounting clips for easy installation on walls or ceilings.

